



## 40000 Series

## Push Button Interface Board Replacement (PBIB-1)



1. Unplug Electrical Assembly and move to a location with adequate workspace.



3. Lift cover up and remove rear enclosure.



5. Locate the Push Button Interface Board and remove (2) screws.



2. Remove (2) screws from the front enclosure,(2) on each side and (4) from the rear enclosure.



4. Lift front enclosure and remove.



6. Once screws are removed, pull board back with caution.



## 40000 Series


## Push Button Interface Board Replacement (PBIB-1)



7. Pull outer tabs out and disconnect ribbon from Push Button Interface Board.



9. Replace housing cover assembly back in unit.



8. Install new Push Button Interface Board and Replace the (2) screws used to remove the Push Button Interface Board.



- 11. Replace the eight (8) screws in the housing. Two (2) in the front, one (1) on each side, and four (4) in the rear.
- 12. Place Electrical Assembly on the Big-Dipper unit and connect the unit to a power source.